

## THE WATER SEPARATOR



The Water Separator works to protect your HP60 or HP-PLUS System by preventing bulk water from passing through it when drying in a negative mode. It should be used after the initial vacuuming with a truckmount system to capture the remaining water that could be undetected. The Water Separator will collect bulk water that may be trapped in ceilings, walls, floors, or cabinets that you are drying. It is no ordinary bucket....The Separator has an anti-collapse ring built into it.

**ORDER #**

**WS**

# WATER SEPARATOR EXAMPLES



The Water Separator shown with the HP60 and Silencer, \*Interceptor HEPA System \*(sold separately)

