

IMPORTANT Read These Instructions Before Use & Save Instructions & Packaging



The Water Separator works to protect your HP60i blower by preventing bulk water from passing through it when drying in a negative mode. Placing it as we recommend, it will collect hidden bulk water that may be trapped in ceilings, walls, floors, or cabinets that you are drying. The Water Separator should be used during the initial phase of your drying job, after water is extracted with a truck mount unit, and should be monitored by a technician.

IMPORTANT Safety warnings are located on page 2

SAFETY WARNINGS

WARNING

DO NOT remove the attached lid to prevent spillage and drowning hazard.

DO NOT leave unattended if there is even a remote possibility of children being present. Keep children away from any bucket. Even a small amount of water can drown a child.

IMPORTANT

DO vacuum standing and or bulk water with truck mount/portable before using the Water Separator.

DO place the Water Separator on a stable surface.

DO place the Water Separator and its supply hoses out of walkways to reduce trip hazards.

DO run the Water Separator for at least 15 minutes to see if there is an immediate collection. If water starts collecting, stop the HP60i & drain the Water Separator. Continue to **monitor until the water has stopped entering the bucket** (we recommend checking at least every 15 minutes). If **NO** more water has collected for 30 minutes, you can remove the Water Separator from the setup.

DO NOT operate in temperatures over 100 degrees Fahrenheit as it will void the warranty.

GRAY & BLACK WATER

Operators should always follow current IICRC S500 Water Damage Restoration Standards.

TABLE OF CONTENTS

INTRODUCTION.....	1
SAFETY WARNINGS.....	2
HOW TO SET UP WITH HP60.....	3
HOW TO SETUP WITH HP60 AND INTERCEPTOR	3
WARRANTY.....	4
CUSTOMER SERVICE.....	4

HOW TO SETUP WITH HP60



FIRST: Remove the Main T from the end of your AIR IN MAIN hose (left)

SECOND: The female threaded end of the AIR IN MAIN hose will now be threaded onto the 2" male pipe thread on the Water Separator (right).



THIRD: Simply attach your 1 1/2" hose (blank or Active Hose line) to the input ports, and you are now protected from bulk water by the Water Separator (left). If you choose to only attach only one hose to the Water Separator then take one of your Endcap plugs and push into the open 1 1/4" opening to cap off.

HOW TO SET WITH HP60, INTERCEPTOR and SILENCER

STEP 1:
Install the Interceptor HEPA Filter to the AIR IN main hose as you normally would.

STEP 2:
Remove the Quick Connect Main T from the end of Interceptor HEPA AIR IN hose.

STEP 3:
The exposed end of the Interceptor HEPA AIR IN hose (female pipe thread) will thread onto the 2" male pipe thread on the Water Separator.

STEP 4:
Simply attach any of your 1 1/2" hose (blank or Active Hose line) and you are now protected from bulk water by the Water Separator.



IMPORTANT

Due to probable high heat output, the Silencer should be elevated from surfaces that could be damaged by heat. We suggest placing on top of the HP60.

Place the HP60 on a blanket to protect floors. (Many floors do not require refinishing)

WARRANTY

Water Separator - 1 Year

Injectidry Systems guarantees the Water Separator to be free from defects in materials and workmanship for a period of one (1) year from the original purchase date. This warranty is subject to the conditions listed below.

CONDITIONS OF WARRANTY

Water Separator: This warranty will not extend to Injectidry products showing any accidental damage, alteration, normal wear, disassembly, lack of proper maintenance, damage from fire or flood, or operating in anything over 100 degrees Fahrenheit, damage from corrosive or other chemicals, unauthorized repairs, use of non-genuine parts and materials, misuse, or any other causes beyond the control of Injectidry. The warranty obligation extends only to the repairs or replacement of parts found to be defective upon the examination and the decision of Injectidry Systems. The preceding limitations constitute the entire warranty. No other warranty or responsibility is expressed or implied. The warranty includes legal rights to the original purchaser, and additional rights may be available, varying state to state. In addition, Injectidry Systems Repair Department must authorize all incoming products and/or repair work to be completed by an authorized repair center. Injectidry Systems is not responsible for any repairs or modifications to any of its products, unless completed by Injectidry Systems or an authorized service center. We are not responsible for subsequent damaged caused by the user and or its agents.

CUSTOMER SERVICE

Return for Repair Request

You can obtain a Request for Repair Form by calling 800.257.0797 or by going to our website - Services - Repair Dept.

Return Request

You can obtain a Request for Return Form by calling 800.257.0797 or by going to our website - Services - Returns Dept.

Incomplete Shipments

All shortages must be reported within five business days.

Be sure to check the number of cartons or packages. You can compare this count with the total listed on Bill of Lading. Confirm that you have received all cartons or packages pertaining to this shipment.

If quantities do not match, have the delivery driver note shortage. If the missing cartons or packages do not show up in the next few days, contact the Shipping Department and we will reship on a new order.

You must file a Freight Claim for shorted packages if the count differs from the Bill of Lading. For your protection, the carrier who delivers merchandise to your door is responsible for any loss or damages. Acceptance of the shipment by the carrier company is acknowledgement that the articles were delivered to them were in good condition and properly packaged.

Freight Damage

Orders are shipped Freight on Board (F.O.B.) from our warehouse in Lynnwood, WA. If the customer has chosen to ship the order with their own account and or carrier, the customer will be responsible for the filing of the freight damage claim. If the customer chose to use Injectidry's account/carrier, Injectidry will file the freight damage claim. All freight damage should be reported to the Injectidry Shipping Department immediately upon discovery.

Inspect your shipment upon delivery. Have the driver note all visible damage on the waybill before you sign. If the discovery of damage is found after the driver has left immediately call the carrier.

Injectidry chooses our carriers carefully and strives for your equipment to be delivered in a timely and undamaged condition. If a mistake happens we do all we can to communicate the problem with the carrier so that it is not repeated. Please let us know immediately if you have any problems.